



Installation instructions
Audi R8 Spyder

First the rear right wheel has to be removed, lift the vehicle by a lift or jack and secure the vehicle against rolling away and falling down:



Remove now the rear right wheel:



Remove the wheel housing shell (about 10-12 screws). Then you will find the standard solenoid valve behind the upper end of the suspension:



Disconnect the original plug from the solenoid valve and connect the solenoid valve and original plug with the fitting plugs of the control system:



In the area to the right of the wheel is usually enough space to place the control system.
Use the mounting holes of the housing to fix the control system with cable ties:



Insert the earth cable upwards so that it can be reached from upper side.



Then attach the ground cable to the ground point:



Test the function of the control system if possible and then reinstall the wheel housing shell and the rear wheel.



Owner: Christian Müller

Vorstadt 15

94577 Winzer

Germany

Phone: +49 (0) 9901 200981

Fax: +49 (0) 9901 200983

www.special-exhaust.de

info@special-exhaust.de