



Installation instructions
Control Exhaust flap
Audi TTS / RS 8J



At the moment we are having no pictures and more precise information from the removing of the panels before, please use the following points therefore only as unprecise guide at your own risk.

To install the control first the boot floor and the boot sill trim must be removed, the boot sill trim should only be clipped and can be pulled away with some (cautious) force upward.

Then the side trim (driver's side) must be removed.

According to our current information, it is clipped to a large extent and screwed in the lashing.

Then it should look like the following pictures.



Pull the rubber grommet and with the cable a little bit out and pass the cable of the control system through it.
(Note: The larger plug on the controller might only pass through the hole with higher pressure.)
If necessary, cut the rubber grommet a little bit for better passing through of the cable.



Alternatively, the cable can also be passed easier through to this hole:



Like at the other hole cut the rubber grommet a little bit for better passing through of the cable if necessary.



Remove the screws of the wheel housing in the rear bumper like shown on the following picture:



Above the left tailpipe is the solenoid valve:



Disconnect the original plug, and connect it with the matching plug of the control.
Then Connect the second plug of the control with the solenoid valve:



Connect the ground wire of the controller to the ground point in the trunk:



Place the controller at last in a suitable location in the trunk, for example, behind the side trim, nearby the battery or the area of the spare wheel:



PLEASE NOTE:

The exhaust flap is basically ALWAYS opened on most vehicles at standstill, a test of the "valve opened" function so is only at driving possible. At best, the difference can be heard by holding the throttle or low acceleration in the range 3,000 to 4,000 1 / min.



Owner: Christian Müller

Vorstadt 15

94577 Winzer

Germany

Telephone: +49 (0) 9901 200981

Fax: +49 (0) 9901 200983

info@special-exhaust.de

www.special-exhaust.de